



Telephone Entry System Heater Kit Installation P/N 2600-580

1. Mount the resistor assembly at the top of the cabinet using the magnets supplied. Place the resistor assembly so that it does not touch any wiring. Route the wires so that they are not in contact with the resistors – they will get hot!
2. Mount the thermostat on the opposite side of the cabinet near the bottom of the cabinet using the double-sided tape supplied.
3. The heater kit is supplied with its own 16 Volt, 50 VA transformer. This transformer must be used to power the heater. Do not power the heater from the telephone entry system power transformer.
4. Use 18 AWG 600 volt insulated wire for heater power runs up to 100 feet. Use 16 AWG 600 volt insulated wire for heater power runs up to 200 feet.
5. Do not run heater power wires over 200 feet or use smaller wire than that specified.
6. Thermostat turns heater on at approximately 40°F (4°C) and off at 55°F (12°C).

